

1530 Broadway Road
Dracut, Massachusetts 01826-2830
U.S.A.

978 441-6800
FAX 978 441-0835
sales@majilite.com

MAJILITE

CARE AND CLEANING GUIDE FOR NYTEK® IN HEALTH CARE APPLICATIONS

NOTE: Cleaning and disinfecting products with greater than 20% alcohol content are not recommended for use on Nytek products.

The following products have been evaluated based on their active ingredients and are not expected to visually alter the appearance of the Nytek finish. Majilite recommends testing all cleaners on a small piece, or section of material first.

Majilite's Nytek® faux leather collection consists of more than 40 leather patterns, including our popular Destiny, Finesse, and Prestige grains.

Nytek® faux leathers are used in dental chairs, examination tables, hospital furniture, and other items that require frequent cleaning and disinfection. However following cleaning instructions can apply to any setting where Nytek® materials are used.

Majilite does not endorse any product's specific ability to clean and/or disinfect. Our evaluations were based upon the disinfectants as currently formulated and may not reflect possible future reformulations or modifications by the manufacturers.

Majilite continues to examine the effects on Nytek® of various commercial disinfectants. Our Technical staff is available to answer any questions regarding the cleaners listed below in connection with Nytek® faux leathers.

Disinfecting:

Dilute as directed and apply according to the manufacturers label instructions. The following products have been evaluated based on their active ingredients and are not expected to visually alter the appearance of the Nytek finish. Majilite recommends testing all cleaners on a small piece, or section of material first.

List of Disinfectants for use on Nytek®

WIPES and TOWELETTES

<u>PRODUCT</u>	<u>TYPE</u>	<u>DISTRIBUTOR/ PRODUCT EPA Reg No.</u>
Asepti-Wipes II Disinfecting Towelettes	Quaternary compounds 17% isopropanol	Metrex Research Corp. 9480-6-1677
Birex Disinfectant Wipes	Phenol	Biotrol 46851-10
Caviwipes and Caviwipes XL Disinfecting Towelettes (low alcohol)	Quaternary compounds 17% isopropanol	Metrex Research Corp. 46781-8
Clorox Disinfecting Wipes	Quaternary compounds 2% isopropanol	Clorox Sales Company 5813-79
Clorox Bleach Wipes	Sodium Hypochlorite 0.1-1%	Clorox Sales Company 67619-12-5813
Clorox Commercial Solutions, Clorox Disinfecting Wipes	Quaternary compounds	Clorox Sales Company 67619-9
Lysol Disinfecting Wipes, all scents	Quaternary compounds 2.5 -10% ethanol	Reckitt Benckiser LLC. 777-114
ProSpray Wipes	Phenol	Certol International, Inc. 46851-10
Sani-cloth Bleach Germicidal Disposable Wipes	Quaternary compounds	PDI 9480-8

WIPES and TOWELETTES *continued*

<u>PRODUCT</u>	<u>TYPE</u>	<u>DISTRIBUTOR/ PRODUCT EPA Reg No.</u>
Sani-Cloth Plus	Quaternary compounds 10-12% Isopropanol	PDI 9480-6
Sani-cloth HB	Quaternary compounds	PDI 61178-4
Sani-cloth Disinfecting Wipes	Quaternary compounds	PDI 9480-5-72956
Sporicidin Brand Disinfecting Towelettes	Phenol	Contec, Inc. 8383-7

SPRAYS & LIQUIDS

<u>PRODUCT</u>	<u>TYPE</u>	<u>DISTRIBUTOR/ PRODUCT EPA Reg No.</u>
Birex se	Phenol	Biotrol International 1043-92-51003
Cetylcide II	Quaternary compounds	Cetylite Industries, Inc. 61178-1
Cavicide	Quaternary compounds 17% isopropanol	Metrex Research Corp. 46781-6
Maxi Spray Plus	Quaternary compounds 17% isopropanol	Metrex Research Corp. 46781-6-10597
Sporicidin Brand Disinfectant Solution	Phenol	Contec, Inc. 8383-7
Omni II	Phenol	Certol International, Inc. 46851-5
Oxycide Daily Disinfectant Cleaner	Hydrogen Peroxide; Peroxyacetic acid	ECOLAB 1677-237

Disinfecting with Bleach:

- Wipe the faux leather with a damp cloth to remove all loose dirt and debris
- Prepare a bleach solution with a concentration not to exceed 10% (5000 ppm available chlorine)
- Use an EPA registered product whenever possible and follow the manufacturer's label instructions
- Spray the wet the surface with bleach solution
- The bleach solution should remain on the faux leather surface for no longer than 10 minutes
- Thoroughly wipe off solution with a clean cloth and water
- Allow to dry before use

The following products are currently not recommended for use on Nytek®:

- Products containing alcohol, such as isopropyl alcohol and ethanol, in concentrations above 20%
- The following products contain alcohol above 20%:
 - Coe Spray II "The pump"
 - DisCide Ultra Disinfectant Spray
 - Citrex Hospital Spray Disinfectant
 - Super Sani-Cloth
 - DisCide Ultra Towelettes
 - Lysol, Lysol II
 - Lysol III
 - Lysol Professional

Products containing Iodophors, such as Wescodyne, ProMedyne, and Iodofive are not acceptable for use on Nytek® due to concerns with possible staining of the Nytek® surface.